



CAUTION



Radial Arm Saw

- Keep work area clean.
- Be sure available dust collection system is operating.
- Before you begin:
 - Inspect workpiece for nails, screws, knots, etc.
 - Replace dull, cracked, or excessively fouled saw blades.
 - Be sure saw returns to starting position when released and does not travel beyond working edge of table.
 - Be sure kickback dogs are properly adjusted and in place.
- Use stick/brush to remove scraps from work table.
- Use proper saw blade for material being cut.
- Do not use abrasive, cutoff, or wire wheels.
- Use workpiece clamps when cross cutting.
- Never exceed rated RPM of saw blade.

Note: Immediately report all machinery malfunctions to the supervisor.